

--> Display at 00:00:00:14
Announcer: A few of WeatherTech
Side Window Deflectors require
S-Clips for installation to
ensure proper window operation.

--> Display at : : :
First, locate the S-Clip
and note that one arm of
the clip is shorter than the
other.

--> Display at : : :
It is this arm of the clip that
needs to be inserted between the
door framing and the
rubber weatherstrip.

--> Display at : : :
Before installing your
deflectors, make sure the window
and window channels are
completely clean and dry.

--> Display at : : :
Wrap a paper towel around the
flat end of the channel tool and
sweep it through the window
channel and weatherstrip,
cleaning it of dirt and debris.

--> Display at : : :
Next, insert the short arm of
the S-Clip into the rear end of
the window, making sure to keep
the top of the clip about 3/8ths
of an inch from the top of the
doorframe.

--> Display at : : :
Then slide the machined flange
of the deflector into the
forward window channel.

--> Display at : : :
It is very important that the
front end of the deflector
flange rests on top of the outer
windowsill weatherstrip as you
slide the machine flange into
the forward window channel.

--> Display at : : :

With the front end in position,
bow the deflector toward you and
slip the rear end flange into
the longer arm of the S-Clip.

--> Display at : : :
Now, working along front to
back, pull down and tuck the
flange up into the window
channel.

--> Display at : : :
A little outward pressure helps
seat the deflector properly into
the channel.

--> Display at : : :
Then slowly raise the window to
fully seat the deflector into
the window channel.

--> Display at : : :
Repeat the process on the other
side, and your WeatherTech Side
Window Deflectors are installed.